

Hanging Personal Safety Partition Assembly Instructions





Hanging Personal Safety Partition Assembly Instructions

Assembly / Installation Process

- 1. Start by identifying the various parts from the list (above). Also, check the quantities.
- 2. Unroll the Panel Assembly, then orient the Logo in the lower right corner.
- 3. Slip an "S" Hook through each slot in the Top bar. Crimp the ends shut with a plier tool.
- Slip one end of each chain onto the other end of the same two "S" Hooks, and crimp the ends shut with a plier tool.
- 5. Clip the Side Mounting Clip to the Ceiling Grid next to the wall.

Note: If Installation is not along a wall, use (2) "J" Hooks.

- Clip the "J" Hook onto the Ceiling Grid at about 48" from the first Mounting Clip.
- 7. Slip an "S" Hook into each of these Ceiling Hooks, and crimp the ends closed.
- 8. Raise the Partition Assembly by holding onto the chains.
- Hook the chains onto the "S" hooks at a height which will allow a minimum of 12" of open space between the ceiling and the Partition top.
- 10. When the proper height is achieved, crimp the "S" Hooks closed with a plier tool.
- 11. Attach, and crimp, "S" hooks between the loose ends of the Chains and the taught portion of the Chain.
- 12. Attach the Foam Bumpers to the Bottom Beam of the Panel Assembly by peeling off the tape backing and pressing the Bumper onto the end of the Bottom Rail.

