



***IMPROVING PROFITABILITY THROUGH
FLEXIBLE SPACE SEPARATION***

Manufacturers of the Original Goff Curtain Walls
700 Hickory Street Pewaukee, Wisconsin 53072

Phone: 800-234-0337 Fax: 262-691-3255

Email: sales@goffscw.com Web: www.goffcurtainwalls.com

Tear Patch Kit Application Instructions

1. Make sure curtain wall is clean, dry and at room temperature.
2. Repair patch may be cut to size with scissors. Trim corners round before removing backing.
3. If more than one patch is required, overlap the separate patches by 1”.
4. Make sure the patch extends 1” on all sides of tear.
5. Peel back ½” of protective backing.
6. Position and anchor exposed ½” edge. Slowly remove backing on patch, remove air pockets and seal the edges. Rub patch firmly.

If additional assistance is needed, please call Goff's Technical Support at 800-234-0337